





Set:
FOX


System Gemini 10




SEVROLL[®]




COMPONENTS





Długość 2.7 m.





Length 1.7m, 2.35m, 3m, 4.05m.



Length 1.7m, 2.35m, 3m, 4.05m.



Length A, B 1.7m, 2.35m, 3m.




You must remember to purchase self-tapping screws to construct each door (4 screws per door).
When using mirror or safety glass you must also remember to purchase seals.

With "10" set you may also use bottom track *Elegant* along with bottom carriage WD 10 V HI-TEC. Fitting measurements are not affected.

Opcja: tor dolny ELEGANT


With "10" set you may also use bottom track *Elegant* along with bottom carriage WD 10 V HI-TEC. Fitting measurements are not affected.



Stopper

Fastening of lower track (special screws)

Dimensions of opening





Handle length = door height

door filling - 10mm board, mirror or safety glass.

door height	- h	$h = H - 38\text{mm}$
board height	- hb	$hb = h - 60\text{mm}$
door width	- w	$w = (W - 3\text{ mm} + Z)/N$
board width	- wb	$wb = w - 20\text{mm}$
upper horizontal profile length - U lower horizontal profile length - L		$U = L = w - 37\text{mm}$
mirror height	- hm	$hm = hb - 4\text{mm}$
mirror width	- wm	$wm = wb - 4\text{mm}$

number of doors	- N	2	3	4
total overlap	- Z	36 mm	72 mm	108 mm




ATTENTION !


Mirror (4mm) should be used with a safety backing film. Safety glass (4.5mm) comprises of two thin layers with a film in-between. Both mirror and glass need fitting seals.

Installation method for fitting 10mm board (diag.A) and mirror or glass (diag.B)

- with handle



- with upper horizontal profile



- with lower horizontal profile

